

# SPREADER SETTINGS CONVERSION

## STEPS ARE AS FOLLOWED:

1. Find the LESCO Calibration Gauge setting that is on the bag of LESCO® product
2. Find that setting on the attached conversion chart
3. Cross reference this setting over to your spreader

## EXAMPLE:

Dimension .10% 19-0-6 has a LESCO® spreader setting of 15.  
 Cross referencing it over to a Scott's EdgeGuard DLX would be a spreader setting of 6 [see below].

Please keep in mind that labeled settings on the product bag and those listed below are approximate and should be used only as a starting point. Many factors can influence product delivery rate including but not limited to: Operator walking speed, maintenance history of spreader, weather conditions, etc.



	LESCO® Spreader	PermaGreen	LT Rich/Spyker	Vicon/LESCO® Pendulum	Iely	Anderson's AccuPro	Anderson's SR-2000	Craftsman	Cyclone	Earthway	Ortho	Scott's AccuGreen 1000	Scott's AccuGreen 3000	Scott's EasyGreen	Scott's EdgeGuard DLX	Scott's EdgeGuard Mini	Scott's R8-A	Scott's SpeedyGreen 1000	Scott's SpeedyGreen 2000	Scott's SpeedyGreen 3000	Spyker	Vigoro 4300
240 STANDARD	11	11	3	16	3	K	K	—	3	13	—	—	—	—	4	—	H 1/2	—	—	—	3	4 1/2
	12	12	3 1/4	18	3 1/4	K 1/4	K 1/4	2	3 1/4	13 1/4	2	6 1/2	6 1/2	25	4	4	I	4	5	4	3 1/4	5
	13	13	3 1/2	20	3 1/2	K 1/2	K 1/2	2 1/4	3 1/2	13 3/4	2 1/4	7	7	25 1/2	5	5	I 1/2	5	6	5	3 1/2	5 1/2
	14	14	4	24	4	L	L	2 1/2	4	14 1/2	2 1/2	7 1/2	7 1/2	26	5	5	J	5	6	5	4	6
	15	15	4 1/4	28	4 1/4	M 1/4	M 1/4	3	4 1/4	15 1/2	3	8	8	26 1/2	6	6	J 1/2	6	7	6	4 1/4	6 1/2
	16	16	4 1/4	30	4 1/2	M 1/2	M 1/2	3 1/4	4 1/4	16 3/4	3 1/4	8 1/2	8 1/2	27	6	6	K	6	7	6	4 1/4	7
	17	17	4 1/2	32	4 3/4	N 3/4	N 3/4	3 1/2	4 1/2	17 3/4	3 1/2	9	9	27 1/2	6 1/2	6 1/2	K 1/2	6 1/2	7 1/2	6 1/2	4 1/2	7 1/2