

Spreader Settings -SGN 100 Elite

	LESCO SPREADER	PermaGreen	LT Rich/Spyker	Vicon/LESCO Pendulum	Lely	Anderson's AccuPro	Anderson's SR-2000	Craftsman	Cyclone	Earthway	Ortho	Scott's AccuGreen 1000	Scott's AccuGreen 3000	Scott's EasyGreen	Scott's EdgeGuard DLX	Scott's EdgeGuard Mini	Scott's R8-A	Scott's SpeedyGreen 1000	Scott's SpeedyGreen 2000	Scott's SpeedyGreen 3000	Spyker	Vigoro 4300
SGN 100 Elite	7	7	2 ¼	**	**	**	**	**	2 ¼	**	**	**	**	**	**	**	F½	**	**	**	2 ¼	**
	8	8	2 ½	**	**	I	I	**	2 ½	**	**	**	**	**	**	**	G	**	**	**	2 ½	**
	9	9	2 ¾	13	2 ½	1½	1½	**	2 ¾	**	**	**	**	**	**	**	G ½	**	**	**	2 ¾	**
	10	10	3	14	2 ¾	J	J	**	3	**	**	**	**	**	**	**	Н	**	**	**	3	**
	11	11	3 ¼	16	3	J ½	J ½	2	3 ¼	12	2	6	6	25	4	4	Н½	4	5	4	3 ¼	4½
	12	12	3 ½	18	3 ½	K	K	2 ¼	3 ½	12 ½	2 ¼	6½	6½	25 ½	4½	4 ½	I	4½	5½	4½	3½	5
	13	13	3 ¾	20	3 ½	Κ ½	K ½	2 ½	3 ¾	13	2 ½	7	7	26	5	5	11/2	5	6	5	3 ¾	5½
	14	14	4	22	4	L	L	2 ¾	4	13 ½	2 ¾	7½	7½	26 ½	5 ½	5 ½	J	5 ½	6½	5 ½	4	6
	15	15	4 ¼	24	4 ½	L ½	L½	3	4 ¼	14	3	8	8	27	6	6	J ½	6	7	6	4 ¼	6½
	16	16	4 ½	26	4 ½	М½	M ½	3 ¼	4½	14½	3 ¼	8 ½	8 ½	27 ½	6½	6½	K	6½	7½	6½	4½	7

** = No Information Available

Labeled settings are approximate and should be used only as a starting point. Many factors can influence product delivery rate including but not limited to: Operator walking speed, maintenance history of spreader, weather conditions, etc.